


Switch on equipment with the net switch. The switch is at the side of the control box.



**Nozzle modes for user**

	Ink consumption: 100% Description: Nozzle rows 1 and 2 are at the same time active (300x300dpi).	<b>Quality 100%</b>
	Ink consumption: 75% Description: Nozzle rows 1 and 2 are at the same time active (300x225dpi).	<b>Saving mode 75%</b>
	Ink consumption: 50% Description: Nozzle rows 1 and 2 are at the same time active (300x150dpi).	<b>Saving mode 50%</b>

**Nozzle modes for service and testing**

	Ink consumption: 25% Description: Nozzle rows 1 and 2 are alternating active (150x150dpi)	<b>Servicemode</b>
	Ink consumption: 0% Description: No nozzle active (0x0dpi).	<b>Servicemode</b>
	<b>Nozzle cleaning:</b> Select printing text CL and switch on Printing on/off button.	<b>Servicemode</b>